



Energy-efficient lighting for industrial and commercial applications

GreenUp Waterproof

GreenUp Waterproof is a high efficient and reliable LED luminaire, designed for industrial application with humid and dust protection requirement. It delivers significant energy savings of up to 62% as compared to conventional dual-T8 waterproof. Utilization of UV-shield PC and extrusion process makes it suitable for semi-outdoor environments, and together with the built-in breather ensure a sound performance. With professional optic design and Philips LED module gives the most comfortable light experience of CRI 85.

Benefits

- High energy efficient
- Long lifetime
- Flexible installation

Features

- System efficacy of 105lm/W
- 40,000hrs lifetime (Philips Lumileds and Xitanium®)
- CRI 85 (Professional optic design and Philips LED module)
- Sliding groove for installation
- UV-shield PC and extrusion process, and built-in breather

Application

- Industry
- Corridors / walkways
- Indoor car parks

GreenUp Waterproof

Dimensional drawing

