



Uni DMX controls and accessories

ZXP399 DMX controller 12V 8port

Black

The ZXP399 DMX Controls and Wiring Accessories are to be used with our architectural and facade lighting luminaires (UniFlood C, M and G, UniStrip G4, UniEdge, UniDot G2, UniString and UniBar). DMX Controls include main controller, stand-alone controller, sub-controllers, DMX amplifier and DMX addressing device. Main Controller: Industrial computer that can control up to 6000 DMX universes. Stand-alone Controller: Fits for medium applications with up to 700 DMX universes. Wiring accessories include leader and jumper cables with male and female IP67 connectors and end-caps. Addressing Device: Hand-held device that can write DMX addresses to a whole run on-site within minutes. DMX Amplifier: Compact, IP65 and low power repeater that can amplify the DMX signal for up to 100 meters.

Product data

General Information		Material	
Accessory color	Black		Aluminum
Operating and Electrical		Approval and Application	
Input Voltage	12 DC V	Ingress protection code	IP20 [Finger-protected]
		Protection class IEC	Safety class III
		CE mark	CE mark
Mechanical and Housing		Product Data	
Overall length	228 mm	Full product code	871951494733700
Overall width	197 mm	Order product name	ZXP399 DMX controller 12V 8port
Overall height	66 mm	Order code	911401779642
Dimensions (Height x Width x Depth)	66 x 197 x 228 mm	Numerator - Quantity Per Pack	1

Uni DMX controls and accessories

Numerator - Packs per outer box	1
Material number (12NC)	911401779642
Full product name	ZXP399 DMX controller 12V 8port
EAN/UPC - Case	8719514947337



Dimensional drawing

